4 Channel Constant Voltage Waterproof Power Repeater

Model No.: EV4-WPS

IP67 waterproof/4 Channel/PWM signal input/Constant voltage output/3KV optoelectronic isolation

Features

- Waterproof 12-36V constant voltage power repeater with IP67 rating, suitable for outdoor and damp environment.
- 4 channel, 5A per channel.
- To receive PWM signal control.
- Power repeater in series or in parallel to expand output unlimitedly.
- Apply to single color, dual color, RGB or RGBW constant voltage LED strip or module.



C€ RoHS emc LVD


Technical Parameters


Input and Output	
Input voltage	12-36VDC
Input current	20.5A
Input signal	PWM
Output voltage	4 x (12-36)VDC
Output current	4CH,5A/CH
Output power	4 x (60-180V)
Output type	Constant voltage

Safety and EMC		
ETSI EN 301 489-1 V2.2.3		
ETSI EN 301 489-17 V3.2.4		
EN 62368-1:2020+A11:2020		
ETSI EN 300 328 V2.2.2		
CE,EMC,IVD		
Package		
L165 x W98 x H72mm		
0.492kg		

Warranty and Protection		
Warranty	5 years	
Protection	Reverse Polarity Over-heat Over-load Short circuit	
Environment		
Operation temperature	Ta: -30 °C ~ +55 °C	
Case temperature (Max.)	T c:+85°C	
IP rating	IP67	


Mechanical Structures and Installations






Wiring Diagram

• Parallel connection



User Manual Ver 1.0.0

• Series connection



Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	No power. Wrong connection or insecure.	Check the power. Check the connection.
Wrong color	1. Wrong connection of R/G/B/W wires.	1. Reconnect R/G/B/W wires.
Uneven intensity between front and rear, with voltage drop	 Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. 	 Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater.

Safety & Warnings

- 1. The product shall be installed and serviced by a qualified person.
- 2. Good heat dissipation will prolong the working life of the controller, Please ensure good ventilation.
- 3. Please check if the output voltage of any power supplies used comply with the working voltage of the product.
- 4. Ensure all wire connections and polarities are correct and secure before applying power to avoid any damages to the LED lights.
- 5. If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.

User Manual Ver 1.0.0